

Steps for installing New Oxygen sensor in legacy ST-48 monitors

- 1.) Remove power from the transmitter.
- 2.) Install the new sensor.
- 3.) Apply power while holding the magnetic wand on the EDIT key.
- 4.) When *** COLD BOOT *** is displayed remove the magnetic wand from the EDIT key.
- 5.) The transmitter will automatically restart.
- 6.) When the unit restarts it will display the sensor data.
- 7.) Hit the NEXT key to continue.
- 8.) You will be prompted to update the sensor. Hit the EDIT key to accept.
- 9.) You will then be prompted to backup the sensor. Hit the EDIT key to accept.
- 10.) Once the update and backup have completed the unit will automatically reboot.
- 11.) Sensor data will be displayed again once it reboots. Hit NEXT or allow it to time out.
- 12.) The unit will function properly at this point.
- 13.) Allow some time for the O2 sensor to stabilize.
- 14.) Perform a routine calibration.