
Quickstart Guide







AUTHORIZED DISTRIBUTOR - GasDetectorsUSA.com - Houston, Texas USA

Quickstart Guide


C2 *Protector* Controller with Remote GASMAX / EC Gas Monitor

Ground Shield at C2

Controller



C2 ANALOG INPUT BOARD P/N #10-0221



Wiring & Initial Setup Instructions

- Install the C2 Protector controller and remote GASMAX / EC monitor. As with all sensors, avoid locations subject to excessive heat, directed water spray or dust. A splash guard is recommended on all externally-mounted sensors.
- 2) Connect the C2 input terminals to the remote GASMAX / EC monitor as shown below. Select a wire gauge that is large enough to ensure that there is sufficient loop voltage available. The GASMAX / EC is non-polarized, so either wire may be connected to the C2 +24VDC connection.
- 3) Make sure the selected C2 channel is set to "ON" (see the C2 manual, section 2.2.4d).
- 4) Calibrate the unit to verify proper operation.

GASMAX / EC DISPLAY ASSEMBLY P/N #10-0232

Important:

The GASMAX / EC loop output is non-polarized. Either GASMAX / EC wire may be connected to the +24VDC terminal on the C2.

